

# Mea Firmware + MIDI USB

## Firmware load :

**Option 1** Saving the "firmware.bin" on the SD card and restart

**Option 2** ( requires the Mea version 0.2 or bigger to be installed first:)

Save it on the SD card with a name like "mea.bin," and you will be able to load it from the "code>flasher" menu.

The same applies to the **Emy firmware** to switch from one to another within the main menu.

This function copies the firmware to "firmware.bin" and reboots the system.

Then it deletes deleting the firmware.bin, but it keeps the original with its original name.