Talko as Ginkosynthese Grains

Both Talko 1.1 & 1.2 share some hardware with the Ginkosynthese Grains.

The Grains is also an Arduino module (based on the famous Audino code from Peter Knight) with the 3 first analogues port being used to manipulate the sound

Talko can also do this and the Grains code need just to be tweaked a bit to get the output on pin 3 (very easy to do)

I tested a few examples found here: http://www.ginkosynthese.com/product/grains/

I uploaded some example on the Github and also posted their compiled firmware here so can be uploaded directly using EasyUploader :

---

fresh.hex

TALKO 1.1 control
Sound : sample offset
Pitch : loop length
Speed : pitch

TALKO 1.2 control
Pitch : sample offset
Speed : loop length
Bend : pitch

View this post on Instagram

A post shared by Jean-Luc Deladrière (@polaxis)

[hrtl-cereals-V2]

TALKO 1.1 control
Sound : sample start
Pitch : grain size
Speed : pitch

TALKO 1.2 control


Pitch : sample start
Speed : grain size
Bend : pitch

---


jgb-patternrain-v2

TALKO 1.1 control
Gate : clock in
Sound : select pattern
Pitch : select bank for patterns
Speed : stop/reset and then pattern rotate (to be able to make it fit better to other parts of your music)

TALKO 1.2 control
Gate : clock in
Pitch : select pattern
Speed : select bank for patterns
Bend : stop/reset and then pattern rotate (to be able to make it fit better to other parts of your music)



View this post on Instagram



A post shared by Jean-Luc Deladrière (@polaxis)

---

jgb-RZ1-drums

TALKO 1.1 control
Sound : Pitch CV 0-5 V
Pitch : Play on / off. Set it to max for normal function
Speed : SAMPLE_SELECT between two wavetables 0-5 V

TALKO 1.2 control
Pitch : Pitch CV 0-5 V
Speed : Play on / off. Set it to max for normal function
Bend : SAMPLE_SELECT between two wavetables 0-5 V

If you would like to adapt other Grains code, just let me know so I can post there here too.

Talko 1.2 now available



Talko 1.2 are now in stock, both as kits and as assembled modules.

What’s new in version 1.2

- Rotary encoder for smoother Bank change
- Encoder’s button can be pressed to simulate the gate signal going HIGH and make the module speak.
- Mode selection via a 3 positions switch : Speech – Repeat – VCO
- Growling mode in VCO (turn the Bend pot fully CCW)



My first patches

Beyond having it to speak and bending it in (the obvious) Speech mode, I would recommend testing the Repeat mode by feeding some rhythmic pattern into the Gate entry and particularly playing with the Gate length.

Another fun one is to set it to Bank 0, VCO mode, turn the Bend pot fully CCW for growling mode and then play with the Sound, Pitch and Speed pots.

Try also to press the rotary button while the Sound entry is being sequenced in VCO mode to hold notes on and manually alter the sequence.
Do you have a nice patch to recommend ?
Thanks in advance for sharing

EasyUploader

I met Paul Soulsby at Superbooth16 in Berlin, earlier this month.
Paul has developed an amazing piece of hardware based on the ATmega328P: [The Amagatron]



Paul also developed a software to allow applying code without the hassle of using the Arduino IDE, installing libraries and compiling code : EasyUploader

Paul made a special version that supports the reset timing that Talko requires.

So have a look on the [Downloads] page to see how simple it is now to apply new versions of code to Talko.

EasyUploader is really … easy to use and works both on Mac & Windows.

Talko 1.2 is coming soon

Talko is an open source Arduino based LPC speech synthesizer. It’s firmware can be updated via the onboard USB port, using the standard Arduino IDE.

In **Speech** mode, the speech starts with a gate signal and complete before waiting for a new gate signal. The speech has the priority.

In **Repeat** mode, the speech starts and stops with the gate signal going high or low. The gate has the priority and the speech repeats while the gate is high. This mode is very useful to create crazy rhythms.

In **VCO** mode, the LPC engine loops while the gate is high, producing steady notes.

The VCO mode can also produce sounds using white noise instead of tones, making strange throat like sounds.

The sound synthesis can be is driven via CV signals or knobs to choose sounds and alter pitch, speed & bending.

flyer1.2.pdf

LPC encoding for the

Arduino’s Talkie library

Adding new sounds or vocabulary for the Talkie library is not straightforward and I needed a checklist to smoothen the process.
Here are the main steps :

Recording audio with Audacity

- The recording has to be made at 8 kHz with 16-bit depth
- Export to Wav signed 16-bit PCM(note that you can also use Audacity to re-sample the audio to 8000 kHz via the [track/re-sample] menu)

Converting sounds using SoX

Alternatively, you can also convert various audio format to 16 bits 8 kHz with SoX, using the following command:

```
sox audiodump.wav -r8000 -b16 audio-8k.wav
```

Coding with QBOX pro

QboxPro was made to code sounds for the venerable TMS5220 chip that Talkie library is emulating.

It runs only on an ancient system like Window XP or older

[fac_icon icon=”exclamation-triangle” color=”#dd3333″]Note: it seems that QBOX doesn’t like when the audio starts immediately. In that case the compressed audio is totally inaudible, so adding a little pause before the sound starts helps a lot

Installation

Get the software here :

ftp://ftp.whtech.com/pc%20utilities/qboxpro.zip

Don’t forget to install QBOX at the root of the disk : c:\QBOX and to move the QBOXPRO.ini file to c:\WINDOWS

Coding

The process of coding has already been described in detail here : http://furrtek.free.fr/index.php?a=speakandspell&ss=9&i=2

The process goes like this:

- Create a new project using the following project parameters : Byte / 8 Khz / 5220 coding table
- Goto Project and add the audio file
- Choose process using : medium bit rate and pressing OK
- Edit concatenation : insert concatenation after by adding a name; then insert phrase and press ok
- Format it by choosing the first line in the format menu : LPC 10V, 4UV

Arduino code

Recuperate the .bin file that Qboxpro has generated This file contains the LPC stream and need to be translated into C++

I use this small Python script to convert the .bin

```
import binascii
fname="SOUND.BIN"
f = open(fname, "rb")
#print "{",
code ="const uint8_t sp"+ fname[:-4]+"[] PROGMEM ={"
try:
    byte = f.read(1)
    while byte != "":
        # Do stuff with byte.
        byte = f.read(1)
        code = code + "0x"+(binascii.hexlify(byte)) +","
```

```
        #print "0x"+(binascii.hexlify(byte))+" ,",

finally:
    f.close()
    code = code[:-4]
    code = code +"};"
    print code
    print
    print("voice.say(sp"+fname[:-4]+");")
```

Simply paste the script’s outputs at their respective places into the Arduino code and upload

Here is an example I generated with the Mac’s say command (note the 0.3-second silent before the speech starts)[edit : it’s fine with 0.1 too]

```
say -v"Yannick" "[[slnc 300]] Wir sind die Roboter" -r 100 -o roboter.wave
```

then I converted to the appropriate format using SoX

```
sox roboter.wave -r 8k -b16 roboter.wav
```

After the QBOXpro coding and the Python converting, I copied these lines into the Arduino IDE

```
// copy this part before the setup() section

const uint8_t spROBOTER [] PROGMEM ={0x00,0x00,0x00,0x00,0x00,0x00,0x00,0x00,0x00,0x00,0x00,0x00,0x80,0x4a,0x6a,0xca,0xac,0x2a,0x26,0x29,0x79,0x50,0xf1,0xae,0x88,0xae,0xb4,0x2a,0x54,0x33,0x5a,0x87,0x36,0x4b,0x65,0x35,0x8b,0xd3,0xba,0xe6,0x43,0x45,0x44,0x49,0xe9,0x86,0x32,0x61,0x92,0x24,0xad,0x1c,0x36,0x04,0x45,0xe3,0xb6,0x62,0x58,0x25,0xb1,0x58,0x72,0x8a,0x69,0x14,0x25,0x72,0xf1,0x29,0x36,0x17,0x92,0xaa,0x59,0xab,0x58,0x9c,0x28,0xab,0x26,0x9d,0x62,0x71,0x26,0xaf,0x9e,0x74,0xf2,0xc5,0x85,0xac,0x6a,0xf6,0xc9,0x97,0x56,0x94,0xaa,0xc5,0x27,0x9b,0xde,0x50,0x33,0x67,0x9f,0x6c,0x18,0x43,0xcb,0x5c,0x7c,0xb2,0xa2,0x44,0xba,0x6a,0xf2,0xc9,0xaa,0x32,0xce,0xac,0x39,0x27,0x2b,0xc6,0x24,0x63,0xaa,0x9c,0xbc,0xc9,0x60,0x97,
```

```
0x9c,0x7d,0x8a,0xca,0x52,0x5c,0x62,0x76,0xab,0x0a,0x4b,0x51,0x
f3,0xc9,0xa5,0xae,0x2c,0x45,0x34,0x1a,0xa7,0xaa,0x53,0x57,0x25
,0x8f,0x5b,0xca,0x6e,0x42,0x44,0xd4,0x4e,0xc9,0x3b,0x77,0x31,0
xf1,0xd4,0xa5,0xae,0x32,0xc9,0xd4,0x6b,0x9f,0x21,0xab,0xc0,0xc
c,0x28,0x7d,0x8a,0xa2,0x1d,0x33,0x62,0xf4,0x29,0x9b,0x0c,0xcc,
0xf0,0xd1,0xa7,0xec,0x2a,0xd1,0xdd,0x46,0x9f,0xb2,0xeb,0xc0,0x
30,0x1b,0x73,0xca,0xae,0x83,0x42,0x6c,0xcc,0xa8,0xab,0x12,0x09
,0xec,0xaa,0xad,0xac,0x92,0x64,0xdc,0x67,0x97,0xaa,0x28,0xe8,0
xf0,0x72,0x93,0xaa,0x2c,0x61,0x22,0x53,0x75,0x69,0xa2,0xc4,0x6
9,0x0b,0xd7,0xa1,0xb1,0x92,0x37,0xad,0x1c,0xb9,0xc6,0x73,0xcd,
0x2c,0x4f,0xd2,0x9a,0x11,0x5c,0x29,0x42,0x6c,0xa9,0x9b,0x22,0x
76,0xaf,0xca,0xa3,0x1a,0x9c,0x28,0xaa,0x27,0xaf,0x6a,0x49,0x26
,0xcd,0x9e,0x73,0xea,0x65,0x04,0x39,0x6b,0xf6,0xa9,0xa7,0x57,0
xe4,0xa8,0xd9,0xa7,0x1a,0x41,0x48,0x23,0x97,0x9c,0xba,0x1b,0x6
6,0x8b,0x5a,0x7c,0x9a,0x2a,0xdc,0xc4,0x62,0x4e,0x00,0xb4,0x4e,
0x71,0x40,0xf0,0x49,0x0a,0x48,0x6a,0x4d,0x00,0x96,0x8d,0x0b,0x
40,0xf8,0x15,0x05,0x88,0x69,0xb4,0xaa,0x90,0x36,0x45,0x6d,0xf2
,0x29,0x43,0xee,0x12,0xf1,0xc9,0xa7,0x0c,0x75,0x8c,0x3d,0x6b,0
x9d,0x32,0xe4,0x75,0xcc,0x8e,0x7c,0x8a,0x18,0x36,0x31,0xb3,0xf
2,0xca,0x83,0x9e,0x26,0x8d,0x99,0xa9,0xf0,0x66,0x0b,0xd3,0x43,
0xab,0x82,0x85,0x4a,0x61,0x8b,0x45,0x32,0x66,0xd3,0x5d,0x35,0x
4e,0xaa,0x07,0x77,0xd7,0x0a,0x2b,0xad,0x9f,0x54,0xc3,0x33,0xe2
,0x84,0x3a,0xf1,0x2a,0x55,0x89,0xb5,0xd2,0xe0,0xd6,0xd9,0x62,0
xe2,0xc9,0x43,0x59,0x63,0xcb,0x51,0x27,0x8f,0x79,0x52,0xc4,0x6
f,0x9d,0x3c,0xa6,0x4a,0xd5,0x98,0x72,0xb2,0x14,0xca,0x4c,0x7d,
0xd1,0x49,0x53,0x28,0x75,0xc9,0xda,0x2d,0x0d,0x31,0xd4,0x25,0x
ab,0x10,0x80,0x26,0x4b,0x02,0x48,0x6f,0xc1,0xf2,0x6a,0xcd,0x45
,0x54,0x6a,0x4b,0xba,0xf5,0xaa,0xd2,0xc4,0xa3,0x99,0x32,0x35,0
x3c,0xea,0x8c,0xb1,0xab,0x64,0xb7,0xa8,0x7c,0xb6,0xa2,0x4d,0xc
a,0xab,0xf4,0xe9,0x8a,0x56,0x2b,0xcd,0xc1,0xa7,0x2f,0xc1,0xd4,
0xad,0xcb,0x9c,0xbe,0x04,0x73,0xd7,0xac,0x7c,0xc6,0x92,0xdd,0x
5d,0x72,0xce,0x19,0x4b,0x4c,0x0b,0xf5,0x39,0xa7,0x2f,0x21,0x3c
,0x34,0xe6,0x9c,0xa5,0xf8,0x88,0x94,0x5c,0x72,0x8e,0xea,0xc2,0
x4b,0x6d,0xc9,0x59,0xaa,0x4b,0x2f,0xd5,0x26,0x67,0xad,0x2e,0xb
d,0x54,0xd7,0x9e,0xb3,0xba,0xf2,0x52,0x5d,0x73,0xba,0x6a,0xca,
0x4a,0x75,0xcd,0x59,0xaa,0x6b,0x2b,0x91,0x35,0xa9,0xca,0x69,0x
28,0xdc,0x67,0x91,0x2a,0xe4,0xd4,0xd2,0xae,0x88,0xaa,0xe0,0xc7
,0xdc,0xb2,0x01,0xaa,0x82,0xc8,0x2c,0x33,0xdb,0x00,0x00,0x00,0
x00,0x00,0x00,0x00,0x00,0x00,0x0f};

// copy this code in the main loop
```

voice.say(spROBOTER);

and here is how it sounds:

Online Store

Polaxis has now an online shop : Please visit this page to grab my latest modules assembled or as DIY kits

---

Talko

” Have your modular speak out the CV “

Intro

This module is performing realtime lpc synthesis and uses no sampling to produce intelligible voice or … not if you choose to.

This module is developed with the help of the Muffwiggler community : **LPC speech synth module**

Technical details

– format: eurorack

– width: 10hp
– depth: 30 mm skiff friendly
– power: + 12V: 65 ma
– audio : un-filtered 5V PWM carrier at 62500 Hz

Functions

Bank Pot

For the moment it can process 12 sound banks or functions :

0: digits (from 0 to 9) male voice
1: digits (from 0 to 9) female voice
2: spell the alphabet
3: nato alphabet
4: vocabulary
5: big numbers
6: voltmeter (reading the CV voltage)
7: frequency meter (just saying “Hertz” instead of “Volts”)
8: counter (each gate trigger increments the counter while any cv change on the Sound entry resets it)
9: number radio (each gate trigger a 4 number sequence while any change on the Sound entry trigger a new “transmission”)
10: time since cv reset (each gate triggers saying the time in minutes/seconds while any cv change on the Sound entry resets the clock to zero)
11: Random vocabulary
12: Sentences :

– s0 : “set the control for the start of the one”
– S1: “C time slow”
– S2: “start the fire
– S3: “smoke the circuit”
– S4: “turn past the time”

– S5: “stop the machine”
– S6: “too_low for you”
– S7: “fire and ice”
– S8: “heavy machine”
– S9: “new ground circuit”
– S10: “repair the machine”

Changing Banks in trigger mode seems unresponsive because the change occurs only when the current speaking finishes.

Hardware

Sound jack & pot

CV signal in allow to choose the words or phrases to be said. Resets counter in bank N°8 and start a new transmission in Bank 9

Gate jack

Level high start the complete sound in trigger mode. (regardless of it’s length)
If the trigger switch is off, the gate will start the sound and hold it as long as the gate level stays up. Very useful to create crazy rhythms.

It needs a gate signal to produce any sound ! No gate= no sound

Trigger Switch

Choose between trigger mode or loop mode.
In trigger mode the speech has the priority and will complete before starting again on the new signal gate going high.
In loop mode the gate has the priority and the speech can be shopped by a low gate level or can be looped with a high gate

level.

Bend Switch

If bend is on, the bend pot … well, distords the sound.

Speed jack & pot

Change the speed of the voice

Pitch jack & pot

Change the pitch of the voice

Bend jack & pot

Change the amount of bending

Please note that building & coding this module requires minimum Arduino knowledge like installing a com port, installing libraries & uploading code.

Build instructions and **source files**

Secure payment

Secure payment

Our secure payment

With SSL

Using Visa/Mastercard/Paypal

About this service

About us

Polaxis is owned by Hanabi Sprl and is based in Belgium.
The main goal of Polaxis is to develop and sell open source electronic kits and sound machines.
VAT BE881386243

Hanabi SPRL
Rue de saint-hubert, 521 D
5300 Vezin

Terms and conditions of use

General Terms and Conditions

The general terms and conditions describe and regulate the conditions for commercial transactions of and with Hanabi Sprl owner of the Polaxis webstore. In case of legal complications, legal jurisdiction is exercised in Belgium.
Kits and products from Hanabi are sold with the following terms and conditions. If you don’t understand or agree with these terms and conditions, you should not purchase or construct kits or products from Polaxis

Article 1: Object

These general conditions of sale are those in which Hanabi offers the provision of goods and services by electronic means related to the Polaxis trademark on the Polaxis website: http://polaxis.pswebshop.com

Article 2 : Payment

We only accept Paypal payments. Please note you can make a Paypal payment with your credit card without opening a Paypal account if you do not wish to do so.

Article 3 : Taxes

Orders are subject to pay Belgium VAT (21%). Businesses within the EU and outside Belgium are to be invoiced ex-VAT as permitted by law by providing their VAT N°.
it is the responsibility of the buyer to pay customs charges and any applicable VAT on the import of goods into his country, as well as to ensure that the goods comply with the local laws of the importing country.

Article 4 : Delivery

All orders are shipped from Belgium. We usually ship within 2 business days, but please allow us up to 5 business days after the payment has been received for exceptional cases.
Once the parcel has been shipped, you will receive a tracking number via email – except if the chosen shipping option does not provide any tracking information.
Average delivery time is 2-8 days within Europe, 5-15 days outside Europe. These times are indicative and do not constitute a commitment on our part.
It is the responsibility of the buyer to provide a shipping address where postal services are able to deliver the parcel.

In addition, we cannot be held responsible for non-delivery if the provided shipping address cannot be served by the postal service or if the provided shipping address contains errors.
In case of a lost parcel, a minimum of 30 days must elapse before filing an appeal with the carrier. Once the loss is recorded by the carrier, we will reship the goods, except in cases of temporary or permanent unavailability of the product, in which case we will make a full refund of the order.

Article 5: Returns – Retraction

In compliance with the Belgium Consumer Rights Law, the private individual consumer is given a cancellation deadline of seven days from the delivery date of the order.
If you want to return your order, please contact us within 7 days of receipt of your package to obtain a return number. No return package will be accepted without this return number. We only accept returns of complete modules, unopened components bags and unsoldered PCB's.
As part of a return you are responsible for : the cost of returning the goods as well as any damage that may occur during the return transportation (including lost package).
Belgium taxes and customs may apply if you send from a country outside the European Union.

Article 6: Warranty

Items sold in kit are not warranted: It is your responsibility to install the kit properly by carefully following the installation instructions found on our website. Technical support is available from our web forums.
Before buying a kit, make sure you have the skills needed for its installation, its possible debugging and maintenance.

Article 7: Legal information

Trademark: Polaxis is a trademark of the company Hanabi Sprl
Enterprise N°: 0881.386.243
VAT N°: BE0881386243
Address:
Rue Saint-Hubert 521d
Vezin 5300
Belgium